


# SURVIVAL MODE PLAYSET INSTRUCTIONS

6+

## CONTENTS

Playset Interchangeable Pieces



**MOJANG**

Check out [service.mattel.com](http://service.mattel.com) for more information. Please remove everything from the package and compare to the contents shown here. If any items are missing, please contact your local Mattel office. Keep these instructions for future reference as they contain important information. Colors and decorations may vary.


©2016 Mattel. All Rights Reserved. "M" and "Mojang" are trademarks of Mattel, except as noted. Mattel, Inc., 636 Grand Avenue, East Aurora, NY 14052, U.S.A. Consumer Services: 1-800-524-8687. Mattel U.K. Ltd., Weyhall Business Park, Madehurst Road, Madehurst, West Sussex PO20 9JL, England, U.K. Mattel Australia Pty. Ltd., Richmond, Victoria 3121, Consumer Advisory Service - 1300 133 312. Mattel East Asia Ltd., Room 501-09, North Tower, World Finance Center, Harbor City, Hong Kong, China. Tel: (852) 3788-6500. Mattel Philippines, Inc., 11th Floor, 11th Avenue, 7, Bangque South City, No. 8, Jalan Kenchik, 15000 Kuala Lumpur, Malaysia. Tel: 65-78803817. Fax: 65-78803867.



## BEFORE YOU START


### SET UP

**ONE TIME ASSEMBLY!** Snap these parts on BEFORE crafting.



**IMPORTANT:** Mountain Top cannot be detached once assembled.


## CRAFT THIS COMBINATION! 50+ COMBINATIONS TO EXPLORE!



## BASE PLAY FEATURES


### ELEVATOR

Move figure up and down on the elevator!



### WATERFALL/LAVA FLOW


Move block left or right to change between Waterfall and Lava Flow!



### DIAMOND


Find the hidden slot in the base.

Store the diamond in the hidden slot.



### HIDDEN ZOMBIE


There is a hidden Zombie in the base! Locate and push the box down to find it!



## DOORWAY PLAY FEATURES

### SAND BLOCKS

Use sand blocks in your combinations! Try blocking off the doorway with sand blocks!




## MOUNTAIN PLAY FEATURES

### TORCHES

Attach torches to mountain top and craft a torch tower!

Torches can also be attached to any pieces with this slot.



## HOUSE PLAY FEATURES

### DOOR

Enter the house through the door.



### LADDER


The ladder can be connected to any pieces with these 2 slots.




### CRAFTING TABLE

USE THE DIAMOND TO "CREATE" A DIAMOND PICKAXE!

1. Open the Crafting Table.
2. Place diamond in the slot.
3. Press on the diamond and close Crafting Table.
4. Open Crafting Table again to find the Diamond Pickaxe!




5. Place Diamond Pickaxe back in the Crafting Table.
6. Press Diamond Pickaxe and close Crafting Table to reset.
7. Hide the Crafting Table behind the door!




## FIGURES


1. Push the creeper's head for ... exploding creeper action!



2. Push button with shears ... release wool!



## TRY CRAFTING ANOTHER COMBINATION!



## 50+ COMBINATIONS TO EXPLORE! CAN YOU CRAFT THEM ALL?

USE THE INTERCHANGEABLE PIECES AND CRAFT 50+ COMBINATIONS!



## INSTRUCTION SHEET SPECIFICATIONS

Toy:  
 Toy No.: DYT66  
 Part No.: 0970-G2  
 Lang. Code: DOM  
 Trim Size: 630mm W x 297mm H  
 Folded Size: 210mm W x 297mm H  
 Type of Fold: 3 panel  
 # colors: 4C  
 Colors: CMYK  
 Paper Stock: 128gsm Art Paper  
 Paper Weight:  
 EDM No.:

## 3 PANEL Folding Dummy

