



HOW TO PLAY



Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
Do not mix old and new batteries.
Only batteries of the same or equivalent type as recommended are to be used.
Batteries are to be inserted with the correct polarity.
Exhausted batteries are to be removed from the product. The supply terminals are not to be short-circuited.
Dispose of batteries safely.
Do not dispose of this product in a fire. The batteries inside may explode or leak.







E X1

RS3 X6

RS2 X2

YS X1

Item No : FBK47-0970 1101398815-DOM Size : A2 : Woodfree paper 70 gsm : 4C Paper Color Date : 1/26/2017 (Emma Wei)

S1 X2

