
LAUNCH & RACE DESERT TRACK SET INSTRUCTIONS

4+

DRENEY PIXAR

Please keep these instructions for future reference as they contain important information.

CONTENTS



©2016 Mattel. All Rights Reserved. ®and™ designate U.S. trademarks of Mattel, except as noted.

Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500.Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.


© Disnev/Pixar

www.disney.com/cars


service.mattel.com


FCV37 - 0970 1101436096 - DOM


1 APPLY LABELS



2 ASSEMBLY







3 TO PLAY

