

## THE BATMOBILE<sup>TM</sup> HAS JOINED FORCES

NOW YOU CAN RACE THE MOST FAMOUS CRIME FIGHTING VEHICLE OF ALL TIME NUW YUU LAN RACE THE MUST FAMUUS LRIME HUITING VEHILLE UF ALL TIME

AROUND YOUR SMART TRACK MAS PART OF THE HOT WHEELS® AI RACING FLEET. AROUND YOUR SMART TRACK AS PART OF THE HUT WHEELS AT RACING FLEET.

THIS KIT INCLUDES A BATMOBILETM CAR BODY, WHEEL COVERS AND CONTROLLER

CARE DIRECT METHODS AS A SMART CONTROLLER. CARTRIDGE WITH AUTHENTIC BATMAN-STYLE SPEECH AND SOUNDS!

Check out videos and lots more at: hotwheels.com/a

A CAUTION: To prevent entanglement, keep all hair



Based on DC Comics Characters.

BATMAN V SUPERMAN: DAWN OF JUSTICE and all related characters and elements © & ™ DC Comics and Warner Bros. Entertainment Inc.



COLORS AND DECORATIONS MAY VARY.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

service.mattel.com HOTWHEELS.COM



©2016 Mattel, All Rights Reserved, ® and Mesignate U.S. trademarks of Mattel, except as noted, Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 920 to Market. Altrigins reserved. 20 and users a recommendation of the properties o Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.



# TABLE OF ENTS CONTIENTS

- 3 WHAT YOU GET INSIDE
- VEHICLE CUSTOMIZATION
- PREP CONTROLLER & CARTRIDGE
- TROUBLESHOOTING
- BATTERY SAFETY

CHECK OUT VIDEOS AND LOTS MORE AT: HOTWHEELS.COM/AI



## SYSTEM TROUBLESHOOTING Race System isn't working like it should, try these troubleshooting tips.

The cartridge was

removed while the

controller was still on.

#### If your HOT WHE

#### PROBLEM

The controller operates with no sound.

## SOLUTION

### CAUSE

- Plug the cartridge cable back into the controller. Turn the controller off.
- Remember to always turn the controller of Turn the controller back on.
- For a full controller reset, remove the batteries from the controller reset, remove the batteries the controller and press the power button for 5 seconds, then reinsert the batteries.

## BATTERY SAFETY

## In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used. Batteries are to be inserted with the correct
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.



Protect the environment by not disposing of this product with household waste [2012/19/EU]. Check your local authority for recycling advice and facilities.

Operation is subject to the following two conditions:

- [1] This device may not cause harmful interference, and [2] this
- (1) This device may not cause narmful interference, and (2) device must accept any interference received, including interference must accept any interference operation. This equipment has been tested and found to comply with the limits for a class B digital device aureuph to each 15 of the limits for a class B digital device.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential protection against harmful interference. Uses and can radiate installation. This equipment generates. protection against harmful interference in a residential installation. This equipment generates, uses and can radiate installation. This equipment generates, uses and used in radio frequency energy and, if not installed and used in radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful accordance with the instructions. However, there is no interference to radio communications. However, there is no interference will not occur in a particular guarantee that interference will not occur in a particular interference will not occur in a particular guarantee that interference will not occur in a particular interference will not guarantee that interference will not occur in a particular installation. If this equipment does cause harmful installation. If this equipment does cause harmful interference to radio or television reception, which can be interference to radio or television reception, which can be interference to radio or television reception, which can be interference to an or more determined by turning the equipment off and on, the user is determined by turning the interference by one or more encouraged to try to correct the interference by one or more of the following measures:
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for
  help
- NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

# PREP CONTROLLER CONTINUED CARTRIDGE

CONNECT YOUR CARTRIDGE KIT




















b. Open the port cover. c. Plug the cable into the port. d. Press the button to POWER ON your controller. BATMAN™ will now guide you through the game settings.

#### (!) IMPORTANT!

Always make sure that the Controller is turned OFF before the Cartridge cable is inserted or removed. To turn OFF the Controller, press the power button when the Controller is active or by removing the batteries.

a. Press the button to switch off your controller. b. Remove the cable. c. Close the port cover. d. Store back the cable.

Always turn OFF your Controller before removing the Cartridge.



## WENGLE MIZATION CUSTOMIA HOT WHEELS At lets you customize your race vehicle by swapping ATTACH REAR FIRST 1 DETACH AT FRONT SNAP FRONT INTO PLACE RAISE FRAME AND PULL FORWARD CLICK! CHANGING VEHICLE WHEEL COVERS ATTACH (3) DETACH



HOT WHEELS A SMART CAR & CONTROLLER SOLD SEPARATELY, SUBJECT TO AVAILABILITY.

PREP YOUR GAMING CONTROLLER (NOT INCLUDED)

the original battery cover with a Phillips head screwdriver (not included).



SWAP YOUR BATTERY COVER

- Attach the CARTRIDGE KIT to your controller with a Phillips head screwdriver (not included). Batteries not included. Dispose of batteries safely.

