3 TO PLAY

A. Flip visor up



B. Press button to activate lights and sounds.



C. After sounds end, talk into the helmet to activate voice change feature!



NOTE: The voice changer will power down automatically when left idle for a few minutes to prevent the batteries from draining. Press button to power up again.


BATTERY REPLACEMENT


- · Batteries included are for demonstration purposes only.
- Replace the batteries if lights dim or sounds distort.
- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Remove batteries and dispose of them safely.
- Install 3 new 3 AAA (LRO3) alkaline batteries in the orientation (+/-) shown.
- Replace battery cover and tighten screw.
- · For longer life, use alkaline batteries.
- When exposed to an electrostatic source, the product may malfunction. To resume normal operation, remove and re-install the batteries

BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- · Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- · Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- . Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- . Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.






BATMAN VOICE CHANGING TACTICAL HELMET **INSTRUCTIONS**

Please keep these instructions for future reference as they contain important information.

1 CONTENTS



⚠ WARNING: This toy does not provide protection.



©2017 Mattel. All Rights Reserved. ® and [™] designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Financie Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Dilmport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd. , No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.



JUSTICE LEAGUE and all related characters and elements © & ™ DC Comics and Warner Bros. Entertainment Inc.

www.iointheleague.com





1101360120-Dom