



2 TO PLAY

- 1 Load vehicle onto launcher.



- 2 Press to launch! Race off and jump over the cactus patch!



Adjust ramp height for the best jump.


Not for use with some Cars vehicles.

WILLY'S BUTTE STUNT JUMP PLAYSET INSTRUCTIONS

4+

Please keep these instructions for future reference as they contain important information.

CONTENTS



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

©2016 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.

© Disney/Pixar



www.disney.com/cars

service.mattel.com

FTH86-0970
1101328517_DOM




1 ASSEMBLY




2


1



2



3



3