

# JONATHAN ADLER

CRAFTED BY

**Fisher-Price®**



**FLT71**

Keep this instruction sheet for future reference,  
as it contains important information.

Adult assembly is required. No tool needed for assembly.  
Requires seven AA (LR6) **alkaline** batteries (not included).

Tool needed for battery installation: Phillips screwdriver.

**fisher-price.com**



## CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)

1300 135 312 (Australia)

**service.fisher-price.com**

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.  
Hearing-impaired consumers: 1-800-382-7470.

### Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,  
Mississauga, Ontario L5R 3W2; [www.service.mattel.com](http://www.service.mattel.com).

Great Britain: Mattel UK Ltd, Vanwall Business Park,  
Maidenhead SL6 4UB. Helpline: 01628 500303.  
[www.service.mattel.com/uk](http://www.service.mattel.com/uk)

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,  
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,  
Albany 1331, Auckland.

South Africa: Mattel South Africa (PTY) LTD, Office 102 I3,  
30 Melrose Boulevard, Johannesburg 2196.

Jonathan Adler is a registered trademark of Jonathan  
Adler Enterprises, LLC and is being used pursuant to license.  
© 2018 Jonathan Adler, Inc. All rights reserved.

©2018 Mattel. \* and ™ designate U.S. trademarks of Mattel, except as noted.

# PARTS



**Mobile**



**Hub**



**Tummy Wedge**



**Giraffe Toy**



**Elephant Toy**




**Mirror Toy**



**Lion Toy**



**Koala Toy**



**4 Legs**



**2 Monkey Toys**



**2 Links**




**2 Shape Toys**



**Mat**

# ASSEMBLY AND SETUP




1. Insert and “**snap**” the legs into the hub sockets. Pull on each leg to be sure they are attached to the hub.
2. Attach the mobile to the hub.
3. Insert the end of the legs through the loops on the mat.
4. Wrap the straps on the mirror toy around a leg and press together to fasten.
5. Attach the links to the elephant, giraffe or shape toys. Now you can hang two more toys to loops on the gym or tummy wedge.
6. Attach the toys to any of the loops around the gym or on the wedge.

## **WARNING**

To prevent entanglement injury, never place the gym in a crib or playpen. Never add strings, ties or other products to the gym.

# BATTERY INSTALLATION



For longer life, use **alkaline** batteries.




- Loosen the screw in the soother battery compartment door and remove the door.
- Insert three, new AA (LR6) **alkaline** batteries.
- Replace the battery compartment door and tighten the screw.

- Locate the battery compartment door on the top side of the hub.
- Loosen the screws in the battery compartment door and remove the door.
- Insert four, new AA (LR6) **alkaline** batteries.
- Replace the battery compartment door and tighten the screws.
- If the hub electronics begin to operate erratically, you may need to reset the electronics. Remove the batteries and reinstall them.
- When the sounds or lights become faint or stop, it's time for an adult to change the batteries.





- Open the fasteners on the tummy wedge and remove the soother.



- Slide the power switch on the soother to  vibration or  OFF.
- Fit the soother back inside the tummy wedge. Make sure the power switch faces you and the activation button is toward the patterned side of the tummy wedge.
- Close the fasteners.
- If the soother begins to operate erratically, you may need to reset the electronics. Slide the power switch off and back on.
- When vibrations become faint or stop, it's time for an adult to change the batteries.

# DANCING LIGHTS MUSIC & CALMING VIBRATIONS



- ⏻ Power** - When power is ON, make music, light and volume selections.
- 🎵 Long Play Music** - Music plays for up to 20 minutes. Press again and again to change songs; press and hold to turn music off.
- 🎵 Short Play Music** - Listen to one song. When baby bats at the mobile, baby starts another song! Press and hold to turn off music.
- 💡 Lights** - Baby enjoys a twinkling light show.
- 🔊 Volume** - Choose a comfortable volume level for baby. Press again and again to cycle through choices, including turning volume off.

- 🌀 Tummy Wedge** - Press the vibration icon on the patterned side of the wedge to start 10 minutes of calming vibrations.



- Remove the mobile on the gym and attach to baby's stroller for on-the-go fun!



- The giraffe, elephant, shape toys, mat and the tummy wedge are machine washable. **First, remove the soother from the wedge, and the legs and toys from the mat.**
- Machine wash them using cold water on the gentle cycle. Do not use bleach. Tumble dry low heat.
- Wipe the legs, hub, mirror, mobile, links and lion, koala and monkey toys with a clean cloth dampened with mild soap and water solution. Do not use bleach. Do not immerse the soother or the hub.
- The legs can be removed from the hub and stored. Simply squeeze the tabs on both sides of a leg and pull to remove from the hub. Repeat to remove the other legs from the hub.

## Battery Safety Information

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: alkaline, standard (carbon-zinc) or rechargeable.
- Insert batteries as indicated inside the battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of this product in a fire. The batteries inside may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type, as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

## CAN ICES-3 (B)/NMB-3 (B)

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes :

- (1) il ne doit pas produire de brouillage et
- (2) il doit pouvoir tolérer tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre son fonctionnement.

## FCC STATEMENT (UNITED STATES ONLY)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.