


CAUTION – ELECTRIC – TOY: Not recommended for children under 8 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.



CAUTION - SUPERVISION REQUIRED - ELECTRIC TOY - UNPLUG WHEN NOT IN USE.

ADULTS NOTE: PERIODICALLY EXAMINE THIS POWER ADAPTER FOR DAMAGE TO THE CORD, HOUSING OR OTHER PARTS THAT MAY RESULT IN THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY. IF THE POWER ADAPTER IS DAMAGED, DO NOT USE IT.

THIS POWER ADAPTER IS INTENDED TO BE CORRECTLY ORIENTED IN A VERTICAL OR FLOOR MOUNT POSITION.


HELP:

IF TRACKSET MALFUNCTIONS, TURN POWER OFF FOR A FEW SECONDS, THEN ON AGAIN TO RESET. IF BLUETOOTH DISCONNECTS, PRESS BLUETOOTH RESET BUTTON TO RECONNECT DEVICE(S).

CHECK OUT THE <u>FAQ</u> SECTION ON <u>AUGMOTO</u>™ APP OR VISIT <u>WWW.HOTWHEELS.COM/AUGMOTO</u> FOR MORE TIPS AND SOLUTIONS.

POWER SWITCH
O = OFF
I = ON
BLUETOOTH

RESET BUTTON







PERFORMANCE TIPS:

Q: WHY CAN'T MY CAR FULLY ENTER THE PIT LANE TO RECHARGE?

- A: YOUR CAR MIGHT BE TRAVELING TOO FAST OR SLOW WHEN IT ENTERS THE PIT LANE. TO SUCCESSFULLY CHARGE YOUR CAR, PUSH IT INTO THE PIT LANE UNTIL THE GREEN/ORANGE LIGHTS START FLASHING.
- Q. WHAT CAN I DO IF MY CAR KEEPS SLOWING DOWN BY ITSELF ON THE TRACK EVEN THOUGH IT IS CHARGED?
- A. CLEAN THE TIRES WITH TAPE AND REMOVE LINT AROUND THE CAR'S AXLES WITH TWEEZERS OR A TOOTHPICK.







PROTECT THE ENVIRONMENT BY NOT DISPOSING OF THIS PRODUCT OR ANY BATTERIES WITH HOUSEHOLD WASTE. THIS SYMBOL INDICATES THAT THIS PRODUCT SHALL NOT BE TREATED AS HOUSEHOLD WASTE. CHECK YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE AND FACILITIES.

WE WILL PROVIDE SUPPORT AND UPDATES OF THE HW AUGMOTO™ APP THROUGH AT LEAST JUNE OF 2020.

PLEASE SEE <u>HOTWHEELS.COM/AUGMOTO</u> FOR MORE INFORMATION, INCLUDING SUPPORT EXTENSION UPDATES.

THIS TOY MUST ONLY BE USED WITH THE POWER ADAPTER PROVIDED FOR TOYS [MODEL NUMBER: PS60A-0503500U].

TOYS LIABLE TO BE CLEANED WITH LIQUIDS ARE TO BE DISCONNECTED FROM THE POWER ADAPTER BEFORE CLEANING.

THIS TOY IS NOT TO BE CONNECTED TO MORE THAN THE RECOMMENDED NUMBER OF POWER SUPPLIES.

FOR SALE IN THE U.S. ONLY. POWER ADAPTOR IS NOT A TOY.

FOR USE WITH AUGMOTO™ VEHICLES ONLY. SMART DEVICE NOT INCLUDED.
PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

FWK44-0970-1102004240-DOM

©2018 MATTEL.

Apple and the Apple logo are trademarks of Apple Inc. registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Android and Google Play are trademarks of Google Inc. Bluetooth[®] and Bluetooth[®] Smart wordmark and logos are owned by Bluetooth SIG, Inc.

MATTEL