




IMPORTANT!

Check Mobile for Proper Function



- Turn the mobile on to see if the birdies spin while the mobile turns. If all the birdies spin, assembly is correct.
- If one or more birdies do not spin, first turn off the mobile. Turn the birdie until it “**snaps**” in place.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2004 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

PRINTED IN CHINA

G5892pr-0921