



INSTRUCTIONS



THE JOKER™ FUNHOUSE





TO PLAY (CONTD.)

3. CLOSE THE JOKER™ FUNHOUSE GATE.




5. SWING THE JOKER'S MALLETS.




6. ROLL DOWN THE RAMP AND ENTER THE JOKER™ FUNHOUSE!


4■ PLACE THE JOKER[™] IN FRONT OF THE GATE.




NOT FOR USE WITH SOME HOT WHEELS® VEHICLES.

- 7.
- **a.** DON'T GET CRUSHED BY THE JOKER'S MALLETS!







OTHER HOT WHEELS® TRACKS AND SETS SOLD SEPARATELY.

©2018 Mattel. ® and [™] designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312. Mattel South Africa (PTY) LTD, Office 102 13, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-33419052. **4**