

INSTRUCTION SHEET SPECIFICATIONS

Toy: Lil' Gleemerz
Toy No.: GGC97
Part No.: 0970
Lang. Code: DOM
Trim Size: 5.82 " W x 7.75 " H
Folded Size: No folding
Type of Fold: 1 panel
colors: 1C
Colors: Black
Paper Stock: White Offset
Paper Weight: 70 lb.
EDM No.: 00

FOR PRODUCT SOLD IN USA

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

- Below Information Only Suitable for Battery Operated or Dual Supply (battery and transformer) Operated Products.

BATTERY SAFETY INFORMATION

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

How to wake up Lil' Gleemerz™ Babies




Press for ON
Press & hold for OFF

Battery Replacement

Batteries included are for demonstration purposes only. Replace batteries when sounds become distorted or lights become faint, and the play modes do not work properly.

To Replace Batteries

Use a Phillips head screwdriver (not included) to open the battery cover. Insert 3 new button cell (LR44/AG13) batteries as shown. Replace battery cover and tighten screw. When exposed to an electrostatic source, the product may malfunction. If this problem occurs, reset the product by reinstalling the batteries.



Button cell (LR44/AG13) x3
(Included button cell x 3pcs)
For longer life use alkaline batteries.



Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.

Keep this instructions for future reference as it contains important information.

Note: The product is equipped with an auto shutoff feature that helps preserve battery life.



WARNING: This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.