




EPIC ROARIN'

TYRANNOSAURUS REX INSTRUCTIONS

4+

Please keep these instructions for future reference as they contain important information.

CONTENTS



GET JURASSIC WORLD FACTS APP! LEARN MORE ABOUT YOUR DINOSAUR!

App is available for download at no cost, some activities may require in-app purchases. Data rates may apply.

©2019 Mattel. © and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel South Africa (PTY) LTD, Office 102 I3, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-33419052.


GJT60_0970
1101740568-DOM

© Universal City Studios LLC and Amblin Entertainment, Inc. All Rights Reserved.




1: TO PLAY


A. Press the button to roar and chomp.



B. Press and hold the button for an epic roar!



C. Twist the tail to rotate the dinosaur's head.




D. Lift the tail up to put in attack position.

1 dinosaur included. Additional dinosaur sold separately, subject to availability.




E. Press and hold the button to open its mouth and release to bite the smaller dinosaur!


NOTE: For best performance, lift the larger dinosaur off the surface and bite the smaller dinosaur from a tilted angle.



F. Move the tail from side to side for thrashing action!



2 BATTERY REPLACEMENT



- Batteries included are for demonstration purposes only.
- Replace the batteries if sounds distort or vibrations slow down.
- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Remove batteries and dispose of them safely.
- Install 3 new AA (LR6) alkaline batteries in the battery box.
- Replace battery cover and tighten screw.
- For best performance, use only alkaline batteries.
- When exposed to an electrostatic source, the product may malfunction. To resume normal operation, remove and reinstall the batteries.

NOTE: This product is equipped with an automatic shut-off feature that helps preserve battery life.