XRS ROCKET RACING SUPER LOOP


INSTRUCTIONS






Please keep these instructions for future reference as they contain important information.


CONTENTS



1 APPLY LABELS




2 ASSEMBLY




3 / TO PLAY

Set launcher.





2 Lower gate completely to launch and race through the loop at record-breaking speed!




3 / TO PLAY (CONTO.)

(3) Explore more ways to play! Move diverter and set up the race. Launch your car again and make a stunt jump!





OR



©2019 Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service -1300 135 312. Mattel South Africa (PTY) LTD, Office 102 I3, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-33419052.

©Disney/Pixar

www.Disney.com/Cars