

Keep these instructions for future reference as they contain important information.



### What's Included



X2



X3



X1



X1




X1



X1



X1



X1



DK X1



Riser X4



D1 X4



X2



RS2 X4



TR X2



CU4 X1



S1 X3



C X7



C X4



TU4 X1



ES3 X1



AR X1



AL X2



X1



X1

### Helpful Hints



Track marking codes are found on the bottom of tracks and risers.

Some track sections (AR, AL, ES3) are intentionally curved, they are not damaged.

Metal engines will not activate motorized features of TrackMaster™ playsets.


Note: Some engines may not work on this track set.

**Adult assembly required.**


No tools needed.

# Assembly


1



2



3




4




5



6




7





# Track Layouts



Pieces Used:




C X11 D1 X4

S1 X3 CU4 X1 AR X1

RS2 X4 TR X2 DK X1 AL X2

TU4 X1 ES3 X1 Riser X4

# Track Layouts



Pieces Used:


C X11 D1 X4 AL X2 RS2 X4 TR X2 DK X1  
S1 X3 CU4 X1 AR X1 TU4 X1 ES3 X1 Riser X4



# Track Layouts

## Pieces Used:

**C** X9   **D1** X2   **AL** X2   **TR** X2   **DK** X1  
**CU4** X1   **AR** X1   **TU4** X1   **ES3** X1   Riser X4



## Pieces Left Over:

**C** X2   **D1** X2  
**S1** X3   **RS2** X4


# How To Play

1



Set the trees upright, as shown.


2



Use the switch-track to choose the direction for the engine.

# How To Play

3



Place the barrel on top of the roof.

4



Push the barrel down so it falls into the cargo car.

5



The engine is released and knocks down the trees.

6



Unload the barrel at the station.



## CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)  
1300 135 312 (Australia)

[service.fisher-price.com](http://service.fisher-price.com)

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.  
Hearing-impaired consumers: 1-800-382-7470.

### Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,  
Mississauga, Ontario L5R 3W2; [www.service.mattel.com](http://www.service.mattel.com).

Great Britain: Mattel UK Ltd, Vanwall Business Park,  
Maidenhead SL6 4UB. Helpline: 01628 500303.  
[www.service.mattel.com/uk](http://www.service.mattel.com/uk)

Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,  
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,  
Albany 1331, Auckland.

South Africa: Mattel South Africa (PTY) LTD, Office 102 I3,  
30 Melrose Boulevard, Johannesburg 2196.

Thomas the Tank Engine & Friends™



CREATED BY BRIT ALLCROFT

Based on the Railway Series by The Reverend W Awdry.

©2019 Gullane (Thomas) Limited. Thomas the Tank Engine & Friends  
and Thomas & Friends are trademarks of Gullane (Thomas) Limited.

©2019 HIT Entertainment Limited. HIT and the HIT logo are trademarks  
of HIT Entertainment Limited.

©2019 Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted.

**PRINTED IN CHINA.** Mattel East Asia Ltd., Room 503-09, North Tower,  
World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Tel.: (852) 3185-6500.

**WARNING:**  
CHOKING HAZARD - Small parts.  
Not for children under 3 years.

GLL14



**Fisher-Price®**

GLL14-0970-1102236277-DOM