H4648 www.fisher-price.com

Fisher-Price[®]



Crankin' Round Crane

Parts


- Α. Crane Arch
- Β.
- С. Base
- D. Chute

Parts not shown: **Pull Car** 2 Cargo Crates


Please keep this instruction sheet for future reference, as it contains important information.

Adult assembly is required.

No tools needed for assembly.



Assembly



Lots of Lifting and Loading



Squeeze the crane to pick up your cargo.




Lift the crane handle and rotate to move the cargo.



Squ carg

Add your RC Train for the Magic of Ge



RC train and extra track pieces shown are sold separately and subject to availability.



eeze again to drop the go into the chute.

•Motion !



eoMotion[™] rotates the crane.

The more you collect, the more fun it gets!



Multiple track packs used to create this configuration. Each sold separately and subject to availability.





Visit www.fisher-price.com to see the entire world of GeoTrax[™] accessories!

Questions? We'd like to hear from you!

Call Fisher-Price[®] Consumer Relations, toll-free at **1-800-432-5437**, 8 AM - 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, visit us on line at www.service.mattel.com. Write to us at:

Fisher-Price[®] Consumer Relations 636 Girard Avenue East Aurora, New York 14052

For countries outside the United States:

 CANADA: Questions? 1-800-432-5437. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.
GREAT BRITAIN: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500302.
AUSTRALIA: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.
NEW ZEALAND: 16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

 PRINTED IN CHINA H4648pr-0920