


PLEASE NOTE!

BEGINNER PRACTICE MODE



- Press the Start Button once to begin. Press the Start Button again to start a practice match.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2005 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

PRINTED IN CHINA

H9820pr-0921