THOMAS & FRIENDS™ PERCY 6-IN-1 SET

Adult assembly required.
Tool needed: Phillips screwdriver (not included).

INSTRUCTIONS
Keep these instructions for future reference as they contain important information.

service.mattel.com

UNITED STATES
Fisher-Price Inc., 636 Girard Avenue, East Aurora, NY 14052.
Consumer Services: 1-800-432-5437.
CANADA
Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario
Consumer Services/Service à la clientèle: 1-800-432-5437. www.service.mattel.com.
GREAT BRITAIN
Mattel U.K. Limited, The Porter Building, 1 Brunel Way,
Slough, SL1 1FQ, UK. www.service.mattel.com/uk.
NEDERLAND
Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
AUSTRALIA
Mattel Australia Pty Ltd, 658 Church Street, Locked Bag 4870, Richmond, Victoria 3121 Australia. Consumer
Service Centre
1300 135 312.
NEW ZEALAND
Mattel New Zealand, Hickering Drive, Albany 1331, Auckland.
SOUTH AFRICA
Mattel South Africa (PTY) LTD, Office 102 (3, 30 Melrose Boulevard, Johannesburg 2196.

CREATED BY REV. W. AWDRY

Based on the Railway Series by The Reverend W Awdry.
©2022 Gullane (Thomas) Limited. Thomas the Tank Engine & Friends™ and Thomas & Friends™
are trademarks of Gullane (Thomas) Limited.
©2022 HIT Entertainment Limited. HIT and the HIT logo are trademarks of HIT Entertainment Limited.

©2022 Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted. **PRINTED IN CHINA.**
Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui,
HK, China. Tel.: (852) 2185-6000.

HXN26

HMN26-0970-210208004-D240

What's Included



Helpful Hints

Look for codes on the bottom of some track pieces.

This set includes tracks with a bend so that the engine can climb up and travel down!

Some engines may not work on this track set.

Assembly steps marked with a star indicate a permanent assembly. Once these parts are assembled, they can't be taken apart.

Battery Information

REQUIRES:
- Phillips screwdriver (not included) for battery installation.
- Two AAA (LR03) **alkaline** batteries (not included).

1.5V AAA (LR03) x2

BATTERY INSTALLATION
Access the battery compartment by loosening the screw in the bottom of the engine and removing the battery compartment door. Insert batteries with the correct polarity (+ and -) as indicated inside the battery compartment. Re-assemble the halves of the engine and tighten the screw. If the engine begins to malfunction, first check battery installation. You may need to reset the electronics by removing the batteries and reinstalling them. If the engine continues to malfunction or no longer operates, it's time to replace the batteries with fresh batteries. For longer life, use **alkaline** batteries.



BATTERY SAFETY INFORMATION
In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of batteries safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.

Assembly

Track Layouts

1



Parts not used:

D1 x2 RS2 x2 RS3 x2

2



Parts not used:

C x3 X x1

Track Layouts

3



Parts not used:

C x1

4

Parts not used:

D1 x1 RC2 x1
C x1 X x1
RS1 x2

5



Parts not used:

D1 x1 RS2 x2 RC1 x1

6



Parts not used:

D1 x1 RS1 x2 X x1 RR1 x1 C x1 S1 x1 ES3 x1

Front

COVER	BACK	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Back

17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32

Fold



Cyan Magenta Yellow Black Dieline

Item No HMN26-0970
Code 210208004-D240
Size 1100 x 1100 mm
Paper 150gsm FSC mix woodfree paper
Ink 4 Colour
Date 17/6/2022 (Emma Wei)