

radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

90-DAY LIMITED WARRANTY

(This product warranty is valid in the United States and Canada only)

Radica China Limited warrants this product for a period of 90 days from the original purchase date under normal use

against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship. Radica China Limited will not be liable for any costs incurred due to loss of use of this product or other incidental or consequential costs, expenses or damages incurred by the purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.

During this 90-day warranty period, the game will either be repaired or replaced (at our option) without charge to the purchaser when returned prepaid with proof of date of purchase to: **Radica USA, Ltd., 13628-A Beta Road, Dallas, Texas 75244, USA.** Please remove the batteries and wrap the unit carefully before shipping. Please include a brief description of the problem along with your return address and mail it postage prepaid.

Products returned *after* the 90-day period has expired will be repaired or replaced (at our option) for a service charge of US \$10.00. Payment must be made by check or money order. This extended service will only be available for one year from the date of purchase.

IMPORTANT: Before returning the unit for repair, test it with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.



RADICA:®
GAMESTER™
PRO RACER AND "THE UNFAIR ADVANTAGE" ARE
TRADEMARKS OF RADICA CHINA LTD.
© 2001 RADICA CHINA LTD.
PRODUCT SHAPE™
ALL RIGHTS RESERVED

GameCube is a trademark of Nintendo Co., Ltd.

Crazy Taxi is a registered trademark of Sega Enterprises, Ltd.

This product is not designed, manufactured, sponsored or endorsed by Nintendo Co., Ltd. or Sega Enterprises, Ltd.

All other product and company names mentioned are the trademarks of their respective owners.



INSTRUCTION MANUAL

MODEL RC71106

For 1 player / Ages 8 and up

P/N 82365000 Rev.A

INTRODUCTION

Congratulations on choosing the Gamester Pro Racer, the ultimate hand-held racing wheel for the Nintendo GameCube video game system.

CONTENTS

- 1 x Pro Racer
- 1 x Instruction Manual


IMPORTANT

Before using this product, read the GameCube Instruction Manual for safety, health and other information.

PRODUCT FEATURES

1. Steering wheel offering eight-bit analog control.
2. Left analog thumbstick.
3. Right analog C (camera) stick.
4. Five action buttons (A, B, X, Y, and Z).
5. Two triggers (L and R) offering eight-bit analog control.
6. One vibration feedback motor.
7. One eight-way digital directional pad.

8. One digital menu navigation button (Start/Pause).
9. One steering wheel locking ring.



LOCKING RING

The locking ring allows your Gamester Pro Racer to act both as a wheel and a full-featured gamepad. When unlocked, the left side of the Pro Racer will work as a steering mechanism for all of your favorite driving games, and the left analog stick will be disabled. When locked, the steering mechanism will not move, and the left analog stick will be enabled.

TROUBLE SHOOTING

The Pro Racer is not working.

- Make sure the connector plug is firmly connected to the GameCube controller port.
- Check the locking ring and make sure it is in the proper position.
- Reset your GameCube console. **Note:** Do not use the Analog stick, Camera stick, Left trigger and Right trigger while turning on GameCube or it will not be calibrated properly.

MAINTENANCE

- Handle this product carefully.
- Store this product away from dusty or dirty areas.

- Keep this product away from moisture or extreme temperature.
- Do not disassemble this product. If problems persist, consult the Warranty information located at the end of this Instruction Manual.

Please retain this for future reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate