

**GAMESTER**

**Xbox**

# Phoenix for Xbox Live

## Instruction Manual



**THE UNFAIR ADVANTAGE**

**RADICA®  
GAMESTER®**  
DUAL FORCE, PHOENIX AND THE  
UNFAIR ADVANTAGE ARE EITHER  
TRADEMARKS OR REGISTERED  
TRADEMARKS OF RADICA GAMES, LTD.  
© 2002-2004 RADICA GAMES, LTD.  
PRODUCT SHAPES  
ALL RIGHTS RESERVED

Distributed in the U.S. by  
**RADICA USA, Ltd.**  
13628 - A Beta Road, Dallas  
Texas 75244 - 4510, U.S.A.

All other product and company names mentioned  
are the trademarks of their respective owners.  
Not suitable for children under 8 years of age.

This product is officially licensed by Microsoft  
Corporation. Microsoft, Xbox, Xbox Live, the Live  
logo, and the Xbox logos are either registered  
trademarks or trademarks of Microsoft Corporation in  
the United States and/or other countries and are used  
under license from Microsoft.

Please retain this for future reference



**RC73900**

P/N 82384200 Rev A

## INTRODUCTION

Congratulations on choosing the Gamester  
Phoenix for Xbox Live pad, combining a pad  
and voice communication for the ultimate way  
to connect to Xbox Live.

## CONTENTS

- 1 x Phoenix for Xbox Live Pad
- 1 x Communicator Headset
- 1 x Instruction Manual
- 1 x Two Month Free Trial to Xbox Live

## IMPORTANT

- Before using this product, read the Xbox  
Console Instruction Manual for safety, health  
and other information.
- An Xbox Live account is required to use the  
Phoenix for Xbox Live. If you do not have an  
account, use the included 2 month free trial  
coupon with any Xbox Live Online enabled  
software to set up your account.

## USING YOUR PHOENIX FOR XBOX LIVE

The Phoenix Live is the officially licensed pad  
with integrated voice communicator for use on  
Xbox Live.

To set up, simply plug the Phoenix for Xbox  
Live into any available controller port. When  
you power on your Xbox with the pad plugged  
in, the Gamester logo should glow green.  
When offline, the Phoenix for Xbox Live  
functions exactly like a standard pad.

For online or network use, plug the headset into  
the communicator jack next to the expansion  
slot on the top of the pad. Position the  
microphone to where it is most comfortable.  
About an inch from the corner of your mouth is  
optimal for most people. Set the volume to your  
own personal setting and start playing!

Pressing the microphone mute button allows  
you to disable the microphone at any time.  
When the microphone is active, the Gamester  
logo will glow green. When the microphone is  
disabled, the Gamester logo will glow red.

[www.theunfairadvantage.com](http://www.theunfairadvantage.com)

**Invert Switch** - The invert switch makes it easy to play with your own personalized control setup. Turn on to invert the up/down motion of the right analogue stick. Turn off and the controller will function normally. Great for First Person Shooter and Flight games.

**Inline Quick Release Connector** - The Inline Quick Release Connector is added to help protect your Xbox game Console. It is designed to disconnect your gamepad from your console in the event that the gamepad is pulled upon with an unreasonable force. The Quick Release Connector should always remain connected during normal use. Always use the console connector to disconnect controller from the console.

**Expansion Slots** - Similar to the first party pad, the upper and lower expansion slots are slightly different shapes. The upper slot supports Memory Unit, Xbox Live Headset, and all future Xbox modules designed for use in the upper slot. The lower slot supports the Memory Unit and all future Xbox modules designed for the lower slot.

## TROUBLESHOOTING

The controller is not working:

- Make sure the controller is firmly connected to the Xbox controller port.
- Make sure the Quick Release Connector is firmly connected.
- Reset your game console.
- If problem persists, contact Radica customer support.

The controller is operating in reverse:

- Make sure the invert switch is set to your personal preference.

The headset is not working:

- Make sure the headset is firmly plugged into the Phoenix for Xbox Live
- Make sure that the microphone is activated (Gamester logo should be green) and the volume is set to an acceptable level.

The Two Month Free Xbox Live Trial Coupon isn't working:

- Make sure you are setting up a new Xbox Live account, the two month free trial applies to new accounts only!
- If the subscription code on the coupon isn't working or the expiration date has passed, please contact Radica Player Helpline at 1-800-803-9611 and you will be provided with a new coupon code.

Having problems connecting to Xbox Live:

- Please contact Microsoft Tech Support or your high speed Internet provider for more detailed tech support.

## CAUTION

Adult supervision is recommended. We suggest that for every hour of gameplay take a 15-minute break.

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

## 90-DAY LIMITED WARRANTY

(This product warranty is valid in the United States and Canada only)

Radica Games Limited warrants this product for a period of 90 days from the original purchase date under normal use against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship. Radica Games Limited will not be liable for any costs incurred due to loss of use of this product or other incidental or consequential costs, expenses or damages incurred by the purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.

During this 90-day warranty period, the game will either be repaired or replaced (at our option)

## MAINTENANCE

- Handle this product carefully.
- Store this product away from dusty or dirty areas.
- Keep this product away from moisture or temperature extremes.
- Do not disassemble this product. If a problem occurs contact the retailer where the item was purchased.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

without charge to the purchaser when returned prepaid with proof of date of purchase to: **Radica USA, Ltd., 13628-A Beta Road, Dallas, Texas 75244, USA.** Please remove the batteries and wrap the unit carefully before shipping. Please include a brief description of the problem along with your return address and mail it postage prepaid.

**IMPORTANT:** Before returning the unit for repair, test it with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.