



# INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.

## BATTERY REPLACEMENT


- Unscrew the battery cover with a Phillips-head screwdriver (not included).
- Dispose of batteries safely.
- Install 4 new 'AA' (LR6) alkaline batteries in the orientation shown. Batteries not included.
- Replace the battery cover and tighten the screw.
- For longer life, use only alkaline batteries.
- Replace the batteries if vehicle runs slowly.
- This product is not recommended for use on loose dirt or wet surfaces.

### Battery Safety Information


- In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:
- Non-rechargeable batteries are not to be recharged.
  - Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).
  - Rechargeable batteries are only to be charged under adult supervision (if designed to be removable).
  - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
  - Do not mix old and new batteries.
  - Only batteries of the same or equivalent type as recommended are to be used.
  - Batteries are to be inserted with the correct polarity.
  - Exhausted batteries are to be removed from the product.
  - The supply terminals are not to be short-circuited.
  - Dispose of battery(ies) safely.
  - Do not dispose of this product in a fire. The batteries inside may explode or leak.

Bottom view.


4 x 'AA' (LR6)



## TO PLAY



**CAUTION:** To prevent entanglement, keep hair away from wheels.



Protect the environment by not disposing of this product with household waste [2002/96/EC]. Check your local authority for recycling advice and facilities.

© Disney/Pixar

© 2006 Mattel, Inc. All Rights Reserved. Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Relations 1-800-524-8687, service.mattel.com. Mattel Canada Inc., Mississauga, Ontario L4R 5W2. You may call us free at 1-800-524-8687. Mattel U.K. Ltd., Vauxhall Business Park, Weybridge, Surrey TW20 2EX. Helpline 01628590303. Mattel Australia Pty Ltd., Richmond, Victoria, 3121. Consumer Advisory Service- 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimprom & Diedarkan Oleh: Mattel SEA Pte Ltd (993532-P) Lot 13.5, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

K4371-0920 G1

