




Dazzlin' Pets™



INSTRUCTIONS

CONTENTS



CONSUMER INFORMATION
Need Assistance? Visit service.mattel.com or call 1-800-524-8697 (US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern.
SERVICE.MATTEL.COM

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697.
Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303.
Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312.
Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.
Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.
Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Affairs 1 (800) 524-8697.

The pet's paws and the catwalk stage contain magnets. Do not use around items that are sensitive to or affected by magnetic fields.


WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

Please remove everything from the package and compare to the contents shown here.
If any items are missing, please call 1-800-524-8697.


Keep these instructions for future reference as they contain important information.

ASSEMBLY


1 Install the doll stand. It simply snaps on.



2 Insert the step on the front of the runway. The step slides into the slots from underneath.




3 Snap the archway into the slots on the runway. Make sure the front faces the long length of the runway, as shown.




LET'S PLAY!


1 Make sure the doll stand lever is all the way to the back. Place the doll into the shoes on the doll stand.




2 Place the pets onto the runway, using the paw prints as a guide. The pets can be in either location.




3 Move the doll stand lever to the front. The pets come out onto the runway, posing all the way!



4 At the end of the runway, the pets turn, ready to "walk" back. NOTE: You'll feel a slight stop at the front, but keep going. If you want to turn the doll to face towards back, use the thumbwheel on the doll stand.




5 Continue to the beginning of the runway to complete the play.



If the pets fall off the runway, reset the doll stand lever to the beginning before adding the pets again. Only pets with magnets work with this playset. Pets can wear clothing on the runway.

Hang the pet's clothing on the clothing rack.



Present the trophies to the pets after a great show!

