


Water toys sometimes get messy, so please protect play surfaces before use.  
 Drain/rinse/clean/dry all items thoroughly before storing.  
 Color change will last longer if you do not expose this toy to intense heat or direct sunlight for prolonged periods of time.



# Ultimate Pool Party™ Playset



## INSTRUCTIONS CONTENTS



**CONSUMER INFORMATION**  
 Need Assistance? Visit [service.mattel.com](http://service.mattel.com) or call 1-800-524-8697  
 (US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern.  
**SERVICE.MATTEL.COM**

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697.  
 Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303.  
 Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.  
 Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.  
 Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran  
 Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.  
 Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Affairs 1 (800) 524-8697.



**WARNING:**  
 CHOKING HAZARD - Small parts.  
 Not for children under 3 years.

Please remove everything from the package and compare to the contents shown here.  
 If any items are missing, please call 1-800-524-8697.

Keep these instructions for future reference as they contain important information.



TM & © 2007 Mattel, Inc. and/or Origin Products Ltd. All Rights Reserved.

# ASSEMBLY





## COLOR CHANGE

Use icy cold water to add streaks to the doll's hair, dots to the front of the doll's swimsuit, and the pet's clothing. Warm water returns to original colors.



# LET'S PLAY!



Works with pet included only.



## SWING



## HANG OUT ON THE DECK

