



CLOSE CAPE



Pull the handles down several times as shown to close cape.

RESET



Swing back wings.

Mattel, Inc., All Rights Reserved. Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Relations 1 (800) 524-8697. • Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697. • Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. • Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. • Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. • Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel: 03-78803817, Fax: 03-78803867.

BATMAN and all related characters and elements are trademarks of and © DC Comics. (s08)

service.mattel.com




INSTRUCTIONS

5+

Please keep these instructions for future reference as they contain important information.

CONTENTS


**CAPE IS NOT A FLYING TOY.**  
WARNING! Keep away from fire.




INSTRUCTION SHEET SPECIFICATIONS	
Toy:	BM MEGA CAPE AND COWL SET
Toy No.:	M2801
Part No.:	0920
Trim Size:	A4
Folded Size:	A5
Type of Fold:	
# colors:	One
Colors:	Black
Paper Stock:	White Offset
Paper Weight:	70 lb.
EDM No.:	

TO PLAY


1.



2.



3. Adjust the straps for best fit.



4. Pull down as shown to open cape. Make sure pull strings are hanging straight down before pulling.

