
EMPTY WATER

Lift up on the track over the splash pool. Carefully lift up on the splash pool, detaching it from the base. Slide under the track, and remove.

Carefully take the pool to a sink and pour out the water.

Empty the hot tub and pool too.





Need Assistance? Visit service.mattel.com or call 1-800-524-8697 (US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern SERVICE.MATTEL.COM

CONSUMER INFORMATION

Mattel U.K. Ltd., Vanwall Business Park, Maldenhead SL6 4UB, Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.


Aattel, Inc. 636 Girard Avenue, East Aurora NY 14052. U.S.A. Consumer Relations 1 (800) 524-8697.

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697.


Keep these instructions for future reference as they contain important information.


TM + © 2009 Mattel, Inc. and/or Origin Product Ltd. All Rights Reserved.


ASSEMBLY



PLAY!







Water toys sometimes get messy, so please protect play surfaces before use. Drain/rinse/clean/dry all items thoroughly before storing. Overfilling of reservoir may cause leakage.



