




IMPORTANT!
For proper function:

1. Insert legs in base.
2. Insert and **fully tighten all four screws.**



Fisher-Price, Inc., a subsidiary of
Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2009 Mattel, Inc. All Right Reserved.

® and ™ designate U.S. trademarks of Mattel, Inc.

P7639pr-0921

PRINTED IN CHINA