

INSTRUCTION SHEET SPECIFICATIONS

Toy: TS3 ACTION LINKS JUNKYARD ESCAPE

Toy No.: R2387

Part No.: 0920

Trim Size: A4

Folded Size:

Type of Fold:

colors: One

Colors: Black

Paper Stock: White Offset

Paper Weight: 70 lb.

EDM No.:




JUNKYARD ESCAPE INSTRUCTIONS

5+

Please keep these instructions for future reference as they contain important information.

CONTENTS



© 2009 Mattel, Inc. All Rights Reserved.

Mattel, Inc. 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Europa, B.V., Godel 1, 1186 MJ Amstelveen, Nederland. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312 Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867. Mattel, Inc. All Rights Reserved.

R2387-0920




© Disney/Pixar


SERVICE.MATTEL.COM

TO PLAY

Rotate counter-clockwise about 1 turn until crane arm "clicks".



Rotate counter-clockwise about 4 turns until conveyor belt "clicks".




Switch order of stunts for more play.


To play again, reset to illustration 1 above.

ASSEMBLY

1.




b




3.




2.



4.



5.



6.

