



## Assembly





- Insert the fork post up through the hole in the neck of the frame. Make sure the fork is positioned so that the fork covers face the rear wheels.





- Fit the handlebar front to the fork post.  
**Hint:** The handlebar front is designed to assemble to the fork post one way.
- Fit the handlebar back to the fork post and handlebar front. Hold them together firmly.
- First, insert the remaining #8 x 3/4" screws through the outer holes in the handlebar back and tighten.
- Then, insert the #8 x 2 1/4" screw through the center hole in the handlebar back and tighten.

## Label Decoration



- Wipe the trike with a clean, dry cloth to remove any dust or oils before applying labels.
- Apply labels exactly as shown in the illustrations. For best results, avoid repositioning the label after it has been applied.
- Starting at the center of a label rub firmly with a dry cloth, and smooth towards the outer edges to remove air bubbles.

## Label Decoration



## Consumer Information

- Periodically, check the plastic parts and if broken or cracked, dispose of them properly.
- Periodically, check all fasteners regularly to be sure they are tight. If the fasteners are not tight, tighten them as necessary.
- To clean, use a mild soap and water solution and a clean cloth. Rinse clean with water to remove soap residue.

**IMPORTANT!** It is a good practice to start training children very young regarding the importance of helmet use. When children are older and riding bicycles and faster vehicles, it is important that they use a helmet each and every time they ride. For this reason, even while riding a tricycle, it is a good idea to familiarize your child with helmet use, so that it becomes a habit for life. Choose a helmet that complies with requirements of the applicable certifying agency for bicycle helmets.

?

CONSUMER ASSISTANCE

1-800-432-5437 (US & Canada)  
1300 135 312 (Australia)

service.fisher-price.com

Fisher-Price, Inc., 636 Girard Avenue, East Aurora, NY 14052.  
Hearing-impaired consumers: 1-800-382-7470.

Outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,  
Mississauga, Ontario L5R 3W2; [www.service.mattel.com](http://www.service.mattel.com).

Great Britain: Mattel UK Ltd, Vanwall Business Park,  
Maidenhead SL6 4UB. Helpline: 01628 500303.  
[www.service.mattel.com/uk](http://www.service.mattel.com/uk)

Mattel Europa, B.V., Godel 1, 1186 MJ Amstelveen, Nederland.

Australia: Mattel Australia Pty. Ltd., 658 Church Street,  
Locked Bag #870, Richmond, Victoria 3121 Australia.

New Zealand: 16-18 William Pickering Drive,  
Albany 1331, Auckland.

Fisher-Price

GO  
DieGO  
GO!



Please keep this instruction sheet for future reference, as it contains important information.

Adult assembly is required.

Tools required for assembly: Phillips Screwdriver, Hammer and Scrap Block of Wood (not included).

Age: 2-5 years

Weight limit: 55 lbs (25 kg).

[www.fisher-price.com](http://www.fisher-price.com)

Consumer Information

⚠️

WARNING

TO AVOID SERIOUS INJURY:

- Adult supervision is required.
- Never use near cars and other motor vehicles, near streets, steps, sloped driveways, hills, roadways, alleys, swimming pools or other bodies of water.
- Always wear shoes.
- Never allow more than one rider.



#8 x 2¼" Screw - 1



#8 x¾" Screw - 6




.354" Cap Nut - 2\*

FASTENERS SHOWN ACTUAL SIZE

\*We've included one extra .354" cap nut for your convenience.

Parts

- Please save all packaging material until assembly is complete to ensure that no parts are discarded.
- Please wipe each part with a clean, dry cloth before assembly.
- Some parts shown are assembled to both sides of the trike.
- Tighten assembled screws with a Phillips screwdriver. Do not over-tighten the screws.
- Part not shown: Label Sheet.




Assembly

⚠️

CAUTION

This product contains small parts in its unassembled state. Adult assembly is required.

1




PUSH

Seat

Frame

• Fit the seat onto the frame. Push firmly near the back end of the seat to "snap" it into place.

2




Bushing (Grooved Side Down)

Rear Wheel (Indented Side Down)

Wheel Hub (Flat Side Down)

Straight Axle



Straight Axle

Cap Nut

• Place one end of the straight axle into the cap nut. Tap the end of the straight axle with a hammer. **Make sure the cap nut is securely attached to the straight axle.**

• Slide a wheel hub, *flat side down*, onto the straight axle.


• Slide a rear wheel, *indented side down*, onto the straight axle.

• Slide a bushing, *grooved side down*, onto the straight axle.

3

Assembly

5




.354"

• Fit the cap nut on the end of the straight axle.

• Tap the cap nut with a hammer. **Gently pull the rear wheel to be sure the cap nut is securely attached to the straight axle.**

*Hint: You may need the help of another adult to hold the other end of the straight axle in place.*

6



Wheel Hub


Wheel Cap

• Fit the tabs on the wheel cap into the slots in the wheel hub. Push to "snap" the wheel cap in place.

• Repeat this procedure to attach the other wheel cap to the other wheel hub.

4

7



Pedal Axle Tab

Pedal Hub


Pedal Hub

• Fit two pedal hubs onto the pedal axle tabs. Make sure the tabs fit into the slot in each pedal hub.

• Press the pedal hubs into the center of the front wheel until they are flush with the surface of the front wheel.

• Repeat this procedure to assemble the remaining pedal hubs.

8



Front Wheel Assembly

Fork Arms

Groove

Fork Cover

Pedal Axle

• Place the front wheel assembly between the fork arms. Make sure the pedal axle fits into the groove at the bottom of each fork arm.

• Place a fork cover over the pedal axle on one fork arm.

• Insert two #8 x ¾" screws into the fork cover and tighten.

• Repeat this procedure to attach the other fork cover to the other fork arm.