OPEN HERE

Please keep these instructions for future reference as they contain important information.

BATTERY INSTALLATION:
Unscrew and lift away cover from bottom of product.
Replace batteries as indicated inside the battery compartment.
Batteries included are for demonstration purposes only.
For longer life use only alkaline batteries.
If this toy begins to operate erratically, you may need to reset the electronics.
Remove the batteries from the toy and replace them.
Requires 3 "AA" (LR6) batteries.

REQUIRED TOOL: PHILLIPS SCREWDRIVER (NOT INCLUDED).

BATTERY SAFETY INFORMATION
In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
NOTE: Changes or modifications not expressively approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

- THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.
- CET APPAREIL NUMERIQUE DE LA CLASSE B EST CONFORME A LA NORME NMB-003 DU CANADA.

- Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- L'utilisation de ce produit est sujette aux conditions suivantes : (1) il ne doit pas produire de brouillage et (2) il doit pouvoir tolérer tout brouillage reçu, même si ce brouillage est susceptible de compromettre son fonctionnement.

Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities.

CONSUMER ASSISTANCE
1-800-432-5437 (US & Canada)
1300 135 312 (Australia)
service.fisher-price.com

© Disney
Visit DisneyJunior.com
©2011, 2012 Mattel. All Rights Reserved.
® and ™ designate U.S. trademarks of Mattel, except as noted.
MADE IN CHINA.
Consumer Relations - Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. 1-800-432-5437.
Mattel Australia Pty. Ltd., Richmond, Victoria. 3121.
Consumer Advisory Service - 1300 135 312.
Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.
Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel: 03-78803817, Fax: 03-78803867.
Manufactured for and imported into the EU by:
Mattel Europa B.V., Gondel 1, 1186 MJ Amstelveen, Nederland.
Additionally distributed in the EU by:
Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB.
Colors and decorations may vary.
Conforms to the Safety Requirements of ASTM F963.

W5269

ID. W5269-0910G2



support the tail of boat



Platform support
it located below of platform
no color

07/19/2012 Remark for G2
-Removed platform and updated position of Call out on front panel for VE

02/03/2011 Remark for G1
-Added & updated copy on all panel
-Updated background on back panel
-Updated image on front panel
-Added QR code on back panel

LANGUAGE : US English

ASST. NO. (-DASH):	NA (-DE1B)	GRAPHIC DESIGNER:	Tracy Mui
PART CODE:	W5269-0910G2	PI ENGINEER:	Mandy Cheung
SOFTWARE:	Illustrator CS5	PROJECT ENGINEER:	Jackson Xie
COLOR PROFILE/LPI:	GRACoL_EPPC_High Speed / 150 lpi	CS VENDOR:	MOA
CS DATE:	07/20/12		

NOTES TO PRINTER:
1) Proofs accurate for process color only. All spot colors must follow PMS Color Formula Guide or color swatch specified.
2) For any dieline or structure change, signed sample approval by MAPS engineer is required before mass printing.

PROOF APPROVAL
SIGN OFF (GRAPHIC): DATE:

Dieline | Cyan | Magenta | Yellow | Black | PMS 300C