

SMART CYCLE



Tips for Better 3D Viewing

1

Set-Up

- Place the cycle about six feet (1,8 m) your TV to start. Adjust the distance further back (usually for larger screen TVs) as needed!



2

3D Glasses

- Help your child put the 3D glasses on properly - red lens for the left eye and blue lens for the right eye. Be sure to use only the red-blue 3D glasses included with this product.

3

Adjust to Improve Picture Quality

- Select the picture settings/mode on your TV. Lower the sharpness or choose a mode like "games".
- Make sure the image ratio setting on your TV is set to 4:3.
- Turn off the 3D effect if you are using this product with a 3D TV.
- Try using a smaller TV.

Fisher-Price

www.fisher-price.com

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2011 Mattel, Inc. All Rights Reserved.
® and ™ designate U.S. trademarks of Mattel, Inc.