





4+

CRASH 'N' CHANGE SPEEDWAY™ Track Set

INSTRUCTIONS



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.


©2011 Mattel, Inc. All Rights Reserved.
Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Yanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria, 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(983532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 P.J. Tel:03-78803817, X0775-0920G1 Fax:03-78803867.

© Disney/Pixar, Gremlin™

service.mattel.com




2 WIND UP AND LOAD CAR.
KEEP WINDING FOR CONTINUOUS ACTION!




NOT FOR USE WITH SOME CARS VEHICLES.

3 LOAD MORE CARS FOR CRASH ACTION!







ADDITIONAL VEHICLES NOT INCLUDED.

4 BLAST THROUGH BILLBOARD!




set up

HELPFUL HINT:
APPLY LABELS BEFORE ASSEMBLY.




APPLY LABELS



TO Play

1 a CRASH CAR FOR INSTANT TRANSFORMATION!



b OR PRESS BUTTON TO TRANSFORM.