




INSTRUCTIONS

SUPER 6-SHOOTER


CONTENTS

Please keep these instructions for future reference as they contain important information.




WARNING:
CHOKING HAZARD - Toy contains small balls. Not for children under 3 years.

ASSEMBLY




TO PLAY

- Position fingers as shown.
 - Push together.
 - Wheels fold in automatically.




- Load launcher on a flat surface.
- Hold launcher at back before firing. Then pull the handle all the way back.



NOTE: Chamber to LEFT of barrel fires first.

- And release to fire. For best launch performance, pull back and release quickly in one continuous action.



Warning: Do not aim at eyes or face. Only use vehicles intended for use with this toy. Do not fire at point-blank range.

INSTRUCTION SHEET SPECIFICATIONS	
Toy No.:	HW COMBAT CANNON
Part No.:	X7146
Trim Size:	0920G2
Folded Size:	8.5"W x 11"H
Type of Fold:	8.5"W x 5.5"H
# colors:	Single
Paper Stock:	Black
Paper Weight:	White Offset
EDM No.:	70 lb.

©2012 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867. service.mattel.com