


TO PLAY


1




2

Connect and load each plane.


A



B




C



3


Let's race!



Not for use with some PLANES vehicles.
Additional PLANES vehicles not included.


4

Winner triggers the checkered flag!



5

Push button to release plane.




SKY TRACK CHALLENGE™ TRACK SET

5+

INSTRUCTIONS

CONTENTS




Spiral track X 2

Straight track X 4

APPLY LABELS

Helpful Hint: Apply labels before assembly by number as indicated.



©2013 Mattel. All Rights Reserved.
Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

© Disney





service.mattel.com

Y0996-0920








ASSEMBLY


1



2



4



5

