



INSTRUCTION SHEET SPECIFICATIONS	
Toy No.:	Y3155
Part No.:	0920
Trim Size:	A4
Folded Size:	
Type of Fold:	accordion
# colors:	One
Colors:	Black
Paper Stock:	White Offset
Paper Weight:	
EDM No.:	001a

3 Land on the flight deck.

a




b




STORAGE

1



STORAGE FOR 6 PLANES

2





AIRCRAFT CARRIER PLAYSET

4+


INSTRUCTIONS

CONTENTS

This is not a water toy.



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.



LABEL SHEET

©2013 Mattel. All Rights Reserved.
Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel: 03-78803817, Fax: 03-78803867.

© Disney


www.disney.com

service.mattel.com

Y3155-0920



Folding Dummy






4 of 4 page

1 of 4 page

APPLY LABELS

HELPFUL HINT: APPLY LABELS BEFORE ASSEMBLY BY NUMBER AS INDICATED.




ASSEMBLY



1

a

b



2





TO PLAY

1 Attach plane. Spin and "fly". Detach and switch planes if desired.

a



b



2 Slide into the Hangar.

a

b



2 of 4 page

3 of 4 page