


TO PLAY

1. Center the flags before play. 2. Load Shell Racers™.



ZIP LINE STUNT RACE™ INSTRUCTIONS

3+

Please keep these instructions for future reference as they contain important information.

CONTENTS

APPLY LABELS

Helpful Hint: Apply labels before assembly by number as indicated.

LABEL SHEET


©2012 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

DreamWorks Turbo © 2013 DreamWorks Animation L.L.C.

Y5797-0920 Asst. Y5795

service.mattel.com

INSTRUCTION SHEET SPECIFICATIONS	
Toy No.:	Y5795
Part No.:	Y5797-0920
Trim Size:	A4
Folded Size:	A5
Type of Fold:	
# colors:	Black
Colors:	White Offset
Paper Stock:	70 lb.
Paper Weight:	
EDM No.:	



ASSEMBLY

- 1.
- 2.
- 3.
- 4.
- 5.
- 6.
- CLICK!
- CLICK!
- For correct operation, attach zipline and connector in orientation shown.