



TO PLAY 3




STORAGE


1. Turn once to lock (Turn again to unlock).




2.



3.



Push button to open.



HOT WHEELS™ BALLISTIKS™ FULL FORCE™



Y6742-0920G1


INSTRUCTIONS

5+

BATTLE WAGON

CONTENTS

Please keep these instructions for future reference as they contain important information.




TRANSFORM

a Position fingers as shown.


b Push together.

c Wheels fold in automatically.





©2013 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 P.J. Tel:03-78803817, Fax:03-78803867. service.mattel.com


SET UP




2. Turn once to unlock (Turn again to lock)



TO PLAY 1



TO PLAY 2



Warning: Do not aim at eyes or face. Only use vehicles intended for use with this toy. Do not fire at point-blank range.