



**SAFETY RECALL!**





**SAFETY RECALL!**



B7080 - Dazzlin' Pet Show™ Magic Rabbits™



J1659 - Polly Pocket!™ Pollywood™ Limo-Scene™ Vehicle



J1660 - Dial-A-Style™ Lila® Doll (J1661)



J1660 - Dial-A-Style™ Lea™ (J1662)



**SAFETY RECALL!**



J1681 - Polly Pocket!™ Pollyworld™  
Rockin' Theme Park™ Playset



J1682 - POLLY POCKET!™  
POLLYWORLD™ Costume Cart (LEA®)  
Playset (J9305)



J1682 - POLLY POCKET!™  
POLLYWORLD™ Gift Shop (Lila®)  
Playset (J9306)



J1687 - Polly Pocket!™ Pollyworld™  
Dress N' Drive™ Lounge Playset



**SAFETY RECALL!**



J9964 - POLLYWORLD DIAL-A SONG  
Polly Fashions (J9965 / J9966)



K0043 - POLLY POCKET!™  
POLLYWORLD™ QUICK CLICK™  
POLLY / CRISSY™ Doll (J4169, J4170)



K0043 - POLLY POCKET!™  
POLLYWORLD™ QUICK CLICK™ LEA /  
SHANI™ doll (J4171, J4172)