




**Meet the Diva Starz™**




28838 Alexa™



28839 Nikki™



28841 Tia™



28840 Summer™

*Dolls sold separately and subject to availability.*

**2 YEAR LIMITED WARRANTY**

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Adjustment Center, 11420 El Valley Boulevard, City of Industry, California 91744 for replacement or refund at our option. This warranty does not cover damage resulting from unauthorized modification, accident, misuse, or abuse. **Valid only in U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Send only the product to the address above. Send all correspondence to Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, California 90245-0017, U.S.A. Or you may phone us toll-free at 1-800-524-TOYS, Monday - Friday, 8:00 a.m. - 6:00 p.m. Eastern Time. See telephone directory for Mattel listing.

**WARNING:**  
**CHOKING HAZARD** - Small parts.  
Not for children under 3 years.

**CONSUMER INFORMATION**

**YOU CAN TELL IT'S MATTEL!™** Call us toll-free or write with any comments or questions about our products or service Monday - Friday 8:00 a.m. - 6:00 p.m. Eastern Time. Outside U.S.A. see telephone directory for Mattel listing.

**Consumer Relations, Mattel, Inc.**  
333 Continental Blvd.  
El Segundo, CA 90245 USA



**1(800)524-TOYS**

**WE ARE DEDICATED TO QUALITY PRODUCTS.**

**Tia** Collectible Series  
doll

**INSTRUCTIONS**

**Contents:**



Please remove everything from the package and compare to the contents shown here. If any items are missing, please call 1-800-524-TOYS.

Keep these instructions for future reference as they contain important information.  
**ADULTS NOTE:** Cut the plastic attachments with scissors and discard pieces. Toy includes 3 button cell batteries.

# LET'S PLAY!




Press the top of her head and Tia™ speaks. Press again for another phrase. (Tia has 4 phrases).



## HELPFUL HINTS:


- Never immerse your Diva Starz™ friend in water.
- Never wash your Diva Starz™ friend's hair.
- If your Diva Starz™ friend gets dirty, wipe clean with a damp, soft cloth.
- If your Diva Starz™ friend's speech becomes slow or garbled, you may need to replace the batteries.



## TO REPLACE BATTERIES

Unscrew battery door screw with Phillips screwdriver (not included) and remove door.

Insert three (3) button cell alkaline batteries as shown. Replace door.



## Battery Safety Information:

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the product before they are charged.
3. If removable rechargeable batteries are used, they are only to be charged under adult supervision.
4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
5. Do not mix old batteries and new batteries.
6. Only batteries of the same or equivalent type as recommended are to be used.
7. Be sure to insert batteries with the correct polarity and always follow the toy and battery manufacturers' instructions.
8. Exhausted batteries are to be removed from the product.
9. The supply terminals are not to be short-circuited.
10. Dispose of batteries safely.