







31784



Instructions

BATTERY INSTALLATION



Toy electronics can be turned off when not in use.

Change batteries if Bubba figure does not talk, his voice sounds scratchy, or he talks intermittently without being activated.

From time to time and with frequent use, you may need to replace batteries.

- To do so, undo the straps of the overalls, and lift the pouch flap in shirt.
- Remove the battery compartment cover using a screwdriver as shown.
- Insert 4 "AA" (alkaline) batteries making sure to match polarity direction of the batteries as indicated on the inside of the battery compartment.
- Replace the battery cover.

CAUTION:

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the product before they are charged.
3. If removable rechargeable batteries are used, they are only to be charged under adult supervision.
4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
5. Do not mix old batteries and new batteries.
6. Only batteries of the same or equivalent type as recommended are to be used.
7. Be sure to insert batteries with the correct polarities and always follow the toy and battery manufacturer's instructions.
8. Exhausted batteries are to be removed from the product.
9. The supply terminals are not to be short-circuited.

©1998 Mattel, Inc. El Segundo, CA 90245 U.S.A.



Squeeze Bubba figure's hand and he will talk. Squeeze the same hand again and he will say something new. Phrases are random, however, they do relate to the previous statement. Bubba offers hours of interactive fun for kids! Note: Bubba says a total of over 200 things (using both hands).



Press flashlight button and you can turn his flashlight on.



When you lay Bedtime Bubba on his tummy you will hear muffled phrases.

CONSUMER INFORMATION

MATTY MATTTEL™ TOYS



YOU CAN TELL IT'S MATTTEL! CALL us toll-free or write with any comments or questions about our toys or service.
Monday-Thursday, 8:00 a.m.-5:00 p.m. PST;
11:00 a.m.-8:00 p.m. EST; Friday, 8:00 a.m.-12:30 p.m. PST;
11:00 a.m.-3:30 p.m. EST. Outside U.S.A., see telephone directory for Mattel listing.
Consumer Affairs, Mattel, Inc., 333 Continental Blvd.,
El Segundo, CA 90245 U.S.A.

1 (800) 524-TOYS



CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

We are dedicated to quality products.

2 YEAR LIMITED WARRANTY

Mattel, Inc. warrants to the original consumer purchaser that this product will be free from defects in material or workmanship for 2 years (unless otherwise specified alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Adjustment Center, 15930 E. Valley Boulevard, City of Industry, CA 91744 for replacement refund at our option. This warranty does not cover damage resulting from accident, misuse or abuse. **VALID ONLY IN U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Send only the product to the address above. Send all correspondence to Consumer Affairs, Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245-5012. U.S. Or you may phone us toll-free at 1-800-524-TOYS, Monday through Thursday 8:00 a.m.-5:00 p.m. PST (11:00 a.m.-8:00 p.m. EST); Friday, 8:00 a.m.-12:30 p.m. PST.