


Barbie


ARCOTOYS, INC., A Mattel Company, warrants to the original consumer purchaser that this toy product will be free from defects in material or workmanship for 2 years (unless otherwise specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date-of-purchase, postage prepaid, to Consumer Adjustment Center, ARCOTOYS, INC., A Mattel Company, C.S. #1015, Westbury N.Y. 11590-0115 U.S.A. for replacement or refund at our option, or you may phone us toll-free at 1 (800) 442-2664, Monday thru Friday between the hours of 10:00 A.M. - 5:00 P.M. EST (7:00 A.M. - 2:00 P.M. PST). This warranty does not cover damage resulting from accident, misuse or abuse. **VALID ONLY IN U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

03


ADULT ASSEMBLY REQUIRED




STEP 1






STEP 2



STEP 3



STEP 4






© 1997 Mattel, Inc. All Rights Reserved.
® and TM designate U.S. trademarks of Mattel, Inc.



WARNING:

CHOKING HAZARD - Small parts.
Not for children under 3 years.

67551-92-070400
PRINTED IN CHINA



67551-92-1



This toy is designed to be assembled one time only.