


Barbie

ADULT ASSEMBLY REQUIRED




ARCOTOYS, INC., A Mattel Company, warrants to the original consumer purchaser that this toy product will be free from defects in material or workmanship for 2 years (unless otherwise specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date-of-purchase, postage prepaid, to Consumer Adjustment Center, ARCOTOYS, INC., A Mattel Company, CS #9008, Crossways Park West, Woodbury, New York 11797 for replacement or refund at our option, or you may phone us toll-free at 1 (800) 442-2664, Monday thru Friday between the hours of 10:00 A.M. - 5:00 P.M. EST (7:00 A.M. - 2:00 P.M. PST). This warranty does not cover damage resulting from accident, misuse or abuse. **VALID ONLY IN U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

03




67791-0700540




STEP 1




STEP 2



STEP 1



STEP 2




© 1998 Mattel, Inc. All Rights Reserved.
 ® and TM designate U.S. trademarks of Mattel, Inc.

BABY HOME NURSERY


WARNING:
 CHOKING HAZARD - Small parts.
 Not for children under 3 years

67791-0700400
 PRINTED IN CHINA





STEP 1

IN UPSIDE DOWN POSITION



STEP 2




STEP 5

STEP 4


STEP 3



STEP 6



STEP 7



STEP 1

STEP 2