


# Pop Around Friends Walker™

## INSTRUCTIONS


Please keep these instructions for future reference as they contain important information.

### Assembly:




Attach Piglet to top of hood by snapping character in as shown.

Insert the handles into the slots as shown.



### Play:

Removable Pooh & Tigger pop up and down as child pushes wagon.



Articulated Pooh turns at the waist

Articulated Tigger turns at the neck



Clicking wheels

Squeaking Horn

This is not a ride-on toy.

Fisher-Price, Inc., a subsidiary of Mattel, Inc.,  
New York, New York 10010 U.S.A.  
Manufactured for Fisher-Price.  
© 2000 Mattel, Inc. All Rights Reserved.  
Fisher-Price, the Fisher-Price logo are  
U.S. trademarks of Mattel, Inc.

Retain this address for future reference:  
Mattel U.K., Ltd., Vanwall Business Park, Maidenhead SL6 4UB.  
Mattel Australia Pty., Ltd., Richmond, Victoria 3121-  
Consumer Advisory Service 1800 800 812 (Valid only in Australia).  
Mattel East Asia Limited, 930 Ocean Centre, Harbour City, HK, China.  
Helpline 01628500303