


Battery Replacement

Toy requires 3 replaceable AA or LR 6 alkaline batteries. Replace batteries when the watercraft moves too slowly in the water. To replace batteries, use a Phillips head screwdriver (not included) to open battery door. Remove and set aside. Insert 3 replaceable AA or LR 6 alkaline batteries as shown. Use either AA or LR 6 alkaline batteries or equivalent. Replace battery cover and screw closed.

ATTENTION: Non-alkaline batteries may not power this toy. Replace with alkaline batteries for longest life and best performance.



BATTERY SAFETY INFORMATION:

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the toy before being charged.
3. Rechargeable batteries are only to be charged under adult supervision.
4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
5. Do not mix old and new batteries
6. Only batteries of the same or equivalent type as recommended are to be used.
7. Batteries are to be inserted with the correct polarity.
8. Exhausted batteries are to be removed from the toy.
9. The supply terminals are not to be short-circuited.
10. Dispose of batteries safely.
11. Do not dispose of in fire as batteries may explode or leak.

Water toys sometimes get messy. Protect play surfaces before use. Drain, rinse, clean and dry all items thoroughly before storing.

CONSUMER INFORMATION

MATTY MATTEL™ TOYS



YOU CAN TELL IT'S MATTEL!™ CALL us toll-free or write with any comments or questions about our products or service. Monday-Friday 8:00 a.m.-6:00 p.m. Eastern Time. Outside U.S.A., see telephone directory for Mattel listing.

Consumer Relations, Mattel, Inc.
333 Continental Blvd.
El Segundo, CA 90245 USA

1(800) 524-TOYS

WE ARE DEDICATED TO QUALITY PRODUCTS.

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.


Barbie® & Kelly®

Dolls

Sea Splashin'™

INSTRUCTIONS

CONTENTS



3 AA batteries required. For longer life use only alkaline batteries. Colors and decorations may vary from those shown.

Please remove everything from the package and compare to the contents shown here.

If any items are missing, please call 1-800-524-TOYS.



B2770-0920

Keep these instructions for future reference as they contain important information.


©2003 Mattel, Inc. El Segundo, CA 90245 U.S.A. All Rights Reserved.

How to play with your Sea Splashin'™ toy!

YOUR DOLLS CAN RIDE THE WATERCRAFT

PUT TOGETHER THE WATERCRAFT




- 1 Pull out the sides of watercraft.
- 2 Slide the center part up and snap onto sides. The front and back snaps on.



PLAY IN WATER

- 1 Install 3 AA alkaline batteries (not included).
- 2 Set rudder for direction.
- 3 Use ON/OFF switch for power.

Works best in water or on smooth surfaces.
Moves on its own only in water.



Float ring does float but will not support doll or dolls.