



Please keep these instructions for future reference as they contain important information.














©2014 Mattel. All Rights Reserved. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Relations 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121.Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Malaysia. Tel:03-78803817, Fax:03-78803867.









ATTACHING MAGAZINE TO BLASTER


A. Open magazine cover.




B. Load rounds.




C. Close magazine cover.



D. Activate and detach shields.




E. Attach magazine to blaster rail.




4 TO FIRE

A. Load all darts into spin barrel.




B. Pull handle all the way back to fire.




NOTE: Unload all darts from spin barrel when not in use.


C. Push handle all the way forward to rotate to next dart.



D. Pull and push handle all the way forward and all the way back repeatedly for rapid fire.




ATTACHING TARGETS



Peel backing off target before sticking it to surface.

Do not stick target to walls or furniture as it may cause damage to the surface.



Always remove darts and rounds from target IMPORTANT: after play. Keep one hand pressed on target, gently peel round off or hold dart by the tip and peel off.



Dust, dirt, and other debris can cause darts and rounds to lose their adhesiveness.

To clean them, rinse darts' tips and rounds with tap water or use tape to remove excess debris.

NOTE: Dry darts and rounds before using again.





Y8620/BBY17

Replace time-worn targets and shields with Y8620/BBY17 SMART STICK REFILLS.

Each sold separately, subject to availability.