

ROCK'EM SOCK'EM ROBOTS

Game




CONTENTS

2 Plastic Robots, 1 Ring, 2 Controllers, 2 Punching Levers

Please remove all contents from the package and compare them to the above list. If any of the items are missing, please contact your local Mattel office.


GAME ASSEMBLY

Slide the controllers into the slots on the side of the ring.



Attach the Punching Levers to the controllers.

Insert the robots onto the controllers.



GAME CONTROLS

Push button - Throw a punch.

OBJECT OF THE GAME

To knock out your opponent's robot by punching it in the jaw and making its head pop up.


HOW TO PLAY

Grasp the controller and rapidly press the control button to throw punches.

Use your free hand to hold the ring steady. Move the controller side to side or back and forth to control the movement of the robot.

Target the head of your opponent's robot. When the robot's head pops up the game is over.

Press down the robot's head to start the next round.



©2017 Mattel. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria, 3121. Consumer Advisory Service - 1300 135 312. Mattel South Africa (PTY) LTD, Office 102 13, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur, Malaysia. Tel: 03-78803817, Fax: 03-78803867.

FMW26-0920
1101619589-DOM

