




INSTRUCTIONS

FIREBALL CRASH™



ADULT ASSEMBLY REQUIRED

COLORS AND DECORATIONS MAY VARY.

REQUIRES 4 "D" SIZE (LR20) ALKALINE BATTERIES (NOT INCLUDED). DISPOSE OF BATTERIES SAFELY.

AGES

5+

service.mattel.com

HOTWHEELS.COM





FTC95-0970
1101664505-DO M G1

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE
REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.






CONTENTS



Refer to letters on toy parts and instructions to help with assembly.




APPLY LABELS







BATTERY INSTALLATION

- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Install 4 "D" size (LR20) alkaline batteries (not included) in the orientation (+/-) shown.
- Replace battery cover and tighten screws.
- For longer life use alkaline batteries.
- Replace the batteries if boosters can no longer propel vehicles through track set.
- When exposed to an electrostatic source, the product may malfunction. To resume normal operation, remove and re-install the batteries.




ASSEMBLY




TAB SHOULD GO OUTSIDE.


4.



5.





6.




IMPORTANT:
MAKE SURE ALL
FLAME PIECES
ARE FIRMLY
ATTACHED
BEFORE PLAY.


7.



8.



9.




BUILDERS TIP!

C



UPPER PART SHOULD GO
OUTSIDE IN "C".



E




UPPER PART SHOULD GO
INSIDE IN "E".

ASSEMBLY (CONTD.)


10.



**RESET METEOR AS SHOWN
AFTER PLAY.**



**TIP: REPLACE RUBBER BAND INTO
SLOTS IF IT DETACHES.**




X2

TO PLAY


1. POWER ON AND LOAD VEHICLES ONTO LAUNCH RAMP. RACE THROUGH THE SPHERICAL TRACK AT TOP SPEED!





I = ON
O = OFF



2. LAUNCH THE EXPLOSIVE ACTION AND BLAST THE METEOR CORE APART!



METHOD 1:
JUMP AND HIT
THE METEOR!





METHOD 2:
COLLIDE IN THE
CRASH ZONE AND
HIT THE CENTER
FLAME!

WARNING: Do not aim at eyes or face. Only use projectiles supplied with this toy. Do not fire at point blank range.

TROUBLESHOOTING TIPS

Q. My vehicle is jammed under the flame. What should I do?

A. Switch off the playset and remove the jammed vehicle. Switch on the playset again to resume normal operation.




Q. My car keeps crashing on the track for no reason. What is the problem?

A. Clear all obstructions on the track. Adjust track side walls at each connection point and make sure they are assembled either INSIDE or OUTSIDE, as described in the assembly steps.


STEP 5

OUTSIDE




STEP 7

OUTSIDE



INSIDE



Q. My vehicle keeps slowing down by itself on the track. What is the problem?

A. Lint can collect around your vehicle's axles. This may cause the vehicle to run slowly. Use tweezers or a toothpick to remove lint.

