



Please keep these instructions for future reference as they contain important information.



WRECKING RIG™ PACK

Build Your Own Adventure™

Born from tough trucks and top technology, Mega Rig® trucks are designed to adapt, react, and conquer. All blueprints, materials and information you are about to see are confidential and for your eyes only! Keep them secret!!!



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.



Requires 3 AG13 (LR44) button cell batteries or equivalent batteries. Batteries included are for demonstration purposes only.

© 2006 Mattel, Inc. All Rights Reserved. PRINTED IN CHINA


With 20 trucks in one, tough jobs get done! But this is about to be your toughest job yet...

You are blasting a road through dangerous Avalanche Canyon. When you hear a deep rumble you know it's not your stomach looking for lunch. It's an avalanche and you better get all your Mega Rig® gear into instant action! **GOOD LUCK!**


MATCH+CONNECT SYSTEM™

Pieces combine and recombine!
Create 20 different trucks!

CONTENTS




BATTERY INSTALLATION/REPLACEMENT




Open battery cover with Phillips head screwdriver (not included) remove batteries included for demonstration purposes only and dispose of them safely. Insert 3 new button cell AG13 (LR44) alkaline batteries as shown. Replace cover and tighten screw. For longer life use only alkaline batteries. Replace batteries when sound distorts or product does not function properly.

ASSEMBLY



Hitch One Rig To Another



CAN YOU BUILD THESE?




CONNECTS TO ANY OTHER MEGA RIG® SET!
NOT FOR USE WITH SOME MATCHBOX® VEHICLES OR SETS.

INSTRUCTION SHEET SPECIFICATIONS

Toy: ARTIC ADVENTURE
Toy No.: K7855
Part No.: 0920
Trim Size: 21.25" W x 5.5" H
Folded Size: 4.25" W x 5.5" H
Type of Fold: accordion
colors: ONE
Colors: 288C
Paper Stock: WHITE OFFSET
Paper Weight: 70 LB.
EDM No.: 009







Folding Dummy



Many ways to play!

Put Matchbox® Men Inside

One Matchbox® figure included, additional figures sold separately.



Battery Safety Information

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).
- Rechargeable batteries are only to be charged under adult supervision (if designed to be removable).
- Exhausted batteries are to be removed from the product.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

RECYCLE INFORMATION (USA ONLY)

Please recycle button cell battery(ies) contained in this product by:

- Visiting your nearest recycling center. For location of the nearest recycling center, visit us online at www.service.mattel.com.
- If a recycling center is not available in your area, contact us for a pre-paid mailing label. Visit us online at www.service.mattel.com or call toll-free at 1-800-524-8697.
- Valid in the US only.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Mattel, Inc.
Consumer Relations
636 Girard Ave
East Aurora, NY
(800) 524-8697

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.



Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities.

Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Relations 1-800-524-8697. www.service.mattel.com Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB, Helpline 01628500303
Mattel Australia Pty Ltd., Richmond, Victoria, 3121. Consumer Advisory Service - 1300 135 312. Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.
Dimport & Distributor: Mattel SEA Pte Ltd (993332-P) Lot 13 S, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ, Tel:03-78803817, Fax:03-78803867.