



INSTRUCTIONS

COLOR-BLASTER™



To view instructions online go to: www.hotwheels.com/instructions.

Please keep these instructions for future reference as they contain important information.

CONTENTS



4+



© 2008 Mattel, Inc. All Rights Reserved.


Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. Consumer Relations 1 (800) 524-8697 service.mattel.com. • Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697. • Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303 • Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. • Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. • Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.

GET READY TO PLAY

1.




2.



For best performance of color change feature, please use cold water under 50°F/10°C.

3.




COLD WATER

4.



5.




86°F/30°C-104°F/40°C
WARM WATER

6.



7.




8.



TO PLAY

1.




2.



3. Aim, fire, transform!




4.



Water toys sometimes get messy. Protect play surfaces before use.


Color change will last longer if you do not expose this toy to intense heat or direct sunlight for prolonged periods of time.

5.




86°F/30°C-104°F/40°C
WARM WATER


Warm water changes color. Cold water changes back. Ambient air temperature can affect color "holding".



6.



COLD WATER



7. Drain, rinse, clean and dry all items thoroughly before storing.

