BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your toy (product). To avoid battery leakage:

- . Non-rechargeable batteries are not to be recharged.
- . Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).
- Rechargeable batteries are only to be charged under adult supervision (if designed to be removable).
- . Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- . Do not mix old and new batteries.
- . Only batteries of the same or equivalent type as recommended are to be used.
- . Batteries are to be inserted with the correct polarity.
- batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- . The supply terminals are not to be short-circuited.
- . Dispose of battery(ies) safely.
- . Do not dispose of this product in a fire. The batteries inside may explode or leak.

For best performance, here is a list of recommended cars for this track set.

Backdraft™ Power Pistons® Side Draft™ Ferrari 348 Ferrari F50 Ballistik™ Sinistra™

Open Road-ster®



Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A.

Consumer Affairs 1 (800) 524-TOYS.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303. service.mattel.com/uk.

Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.

Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui,
HK, China.


Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel:03-78803817, Fax:03-78803867.





INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.





Requires 4 "D" alkaline batteries (not included). **Adult assembly required.**



@ 2005 Mattel, Inc. All Rights Reserved.




Refer to numbers on parts and contents page to help with assembly.

Animated assembly instructions available online! Go to:

http://www.hotwheels.com/H2247_GorillaAttack











INSTALL BATTERIES


Open battery cover and insert 4 "D" size alkaline batteries (not included) as shown. For best performance, use alkaline batteries. Replace the batteries when the booster no longer propels the car through the set.














Turn cannon clockwise until it stops and locks.

