

Learning Pots & Pans™ Recall

Fisher-Price is voluntarily recalling the Learning Pots & Pans™ Playset.

The Learning Pots & Pans™ Playset is a set of stacking pots and pans with a lid and shape-sorting blocks. The product features lights and sounds and operates on 3 "AA" batteries.



Missing screws in the blue pan can cause the clear plastic cover to become loose, releasing small balls which pose a choking hazard.

If you own this playset please remove it from the reach of children and use this online guide to determine if it is affected:

- 1) Please locate the blue pan containing the encased colored balls.



- 2) Please turn the blue pan over and examine the underside. There should be six screws inserted through the bottom of blue pan into the clear plastic cover above.



3) If there are six screws in place on the underside of the blue pan, your product is **not** affected by the recall and you can continue to enjoy your playset.

4) If there are any screws **missing** from the underside of the blue pan, your product **is** affected by this recall. **Please remove the blue pan portion of the Learning Pots & Pans™ playset from the hands of children, immediately.**



Should customers have any concerns about the product please contact Mattel® Pty.Ltd. on 1800-674-753 Monday to Friday between 8am to 5pm (Aust EST) or email infoaust@mattel.com to determine if their product is affected. Consumers should not return the product to retail stores.

We apologize for any inconvenience. Our greatest concern has always rested with the safety of the children who play with our toys, which is why we have responded promptly in an effort to maintain the trust of the families that have allowed us to be part of their lives.