TO PLAY

**1.** Set launcher and load car.


2. Launch to ride the water slide!

Icy water changes color.

3. Piranha Attack™ !

Icy water changes color.   Warm water changes color.

4. Launch to rescue the trapped car!

Color change will last longer if you do not expose this toy to intense heat or direct sunlight for prolonged periods of time.

TO DRAIN

Drain, rinse, clean and dry all items thoroughly before storing. Do not immerse set in water.

1.   **2.**

FEATURING:
MULTI-COLOR CHANGE!

1 Black/Brown/Violet   →   **2** Green/Light Green   →   **3** Yellow

ICY WATER   WARM WATER   WARMER WATER

4 Red

ICY WATER (AGAIN!)

HOT WHEELS
PIRANHA ATTACK ™

INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.

CONTENTS

4+   MATTEL

W1535-0920

EASY ASSEMBLY
Refer to letters on parts and contents page to help with assembly.

4 PANEL Folding Dummy

FRONT
6 7 8 1
COVER

BACK
2 3 4 5

ASSEMBLY

1. Refer to letters on parts and contents page to help with assembly.

2.

3a.   **3b.**

4.
a One-time snap assembly
b
Click!
c One-time snap assembly
d

5.
a   b

6.
1 2 3 4

7.

GET READY TO PLAY

Fill water to top of container for best performance.
Overfilling of reservoir may cause leakage.
To avoid burns do not use water that is too hot, above 120°F(48°C).
Water toys sometimes get messy. Protect play surfaces before use.

For best performance of color change feature, please use icy water under 50°F/10°C.

Icy water

86°F/30°C-104°F/40°C
Warm water

Icy water

Set and Reset